

RANGE 3030PV**EN 14470-1 FM 6050**

EN 14470-1 & FM SAFETY CABINETS TYPE 30-MINUTES with glass doors



Standardized labeling



Adjustable shelf



Pedestal area under-driveable by a forklift



▲3035PVE



▲3034PVE

**CERTIFICATION**

- Tested and approved Type 30-minutes according to EN 14470-1 (04-2004) and EN 1363-1 (06-2000).
- Tested and approved Type 10-minutes according to FM 6050 (Factory Mutual international) - Supplement certification in progress.
- Normalized labelling according to ISO 3864 and EN 14470-1 (04-2004) norms, 92/58/CEE european directive and FM regulations.

ADVANTAGES

- 30-minutes fire resistance according to ISO 834 fire heating curve.
- Pedestal area under-driveable by a forklift by removing panel (except for the under-bench models).
- Self-closing door(s) with possibility to keep the door(s) open. If the temperature rises to 47°C, a fuse link closes the door(s) automatically.
- Glass door(s) for easy sight of the stored products.

PASSIVE SECURITY

- Built in melamine: corrosion proof and overall good chemical resistance.
- Grey structure (RAL 7035), yellow edges (RAL 1023).
- Fireproof glass doors, thickness 17 mm.
- Safety labelling as per EN 14470-1 and FM 6050.

- Containment shelves adjustable in height (step every 32 mm).
- Removable bottom containment sump.

ACTIVE SECURITY

- Ø 100 mm air inlet and outlet ducts for whether natural ventilation or connection with forced ventilation/filtration system.
- Self-closing door(s).
- Door(s) with a lockable three-point latching mechanism.
- Non-sparking locking mechanism.
- Adjustable leveling feet for enhancing stability.
- In case of fire, a thermo-fuse automatically seals off the ventilation system.
- Thermo-expanding seals of the door(s) allow keeping the internal body fireproof.

OPTIONS

- Additional retention shelf.
- Perforated cover plate for containment sump.
- Self retracting shelf.
- PVC containment shelf and containment sump.
- Easy connection with an exhausting system or a filtration box.



P/N	Description	External dimensions H x W x D (mm)	Storage capacity (L)	Delivered with		Maximum load by shelf ⁽²⁾ (kg)	Weight (kg)
				Steel retention shelf	Steel containment sump		
3034PVE	Tall equipped cabinet with one glass door	1980x605x550	130	3	1	30	170
3035PVE	Tall equipped cabinet with two glass doors	1980x1115x550	250	3	1	50	255
E48	Additional steel retention shelf for 3034PVE	30 x 490 x 410	-	-	-	-	3
E35	Additional steel retention shelf for 3035PVE	30 x 990 x 410	-	-	-	-	6
C148	Perforated cover plate for containment sump for 3034PVE	90 x 460 x 390	-	-	-	-	4
C235	Perforated cover plate for containment sump for 3035PVE	90 x 980 x 400	-	-	-	-	8
T148	Self retracting shelf for 3034PVE	80 x 420 x 380	-	-	-	-	6
T235	Self retracting shelf for 3035PVE	80 x 930 x 380	-	-	-	-	12
SE148	PVC containment shelf for 3034PVE for 3035PVE model, 2 pieces by level are required	30 x 475 x 405	-	-	-	-	3
SB148	PVC containment sump for 3034PVE for 3035PVE model, 2 pieces by level are required	100 x 475 x 405	-	-	-	-	4

The manufacturer reserves the right to discontinue or change specifications or designs at any time without notice and without incurring obligations. 07/2019

Flammable cabinets

Corrosive cabinets

Toxic cabinets and multirisk

Pesticide range

Fume hoods, filtering cabinets - Ventilation

Containment and Cans

File cabinets Anti-fire equipments

Showers and first-aid equipments